

Installation instructions

Before installation begins

Check that you have received the correct product and that all materials are from the same batch. Also check that the material has no visible defects. Faulty material is replaced with new material of the same type. Material installed with visible errors is considered accepted and thus does not entitle to a complaint.

When laying the floor, the room temperature must be between +18° and +25° and the relative humidity in the room must be between 25% and 70%.

The floor material must be acclimatized in the room for at least 24 hours before laying the floor. Room temperature must be maintained for at least 72 hours after installation.

Avoid loading the floor for the first 24 hours after installation.

Underfloor heating must be switched off during installation and during the glue's curing time (approx. 1 week). The underfloor heating can then be switched on and the temperature gradually increased. Floors and glue may be exposed to a maximum of 27°C.

Underfloor

The subfloor must be clean, sufficiently dry, even, stable, free of cracks, unevenness and failure. For flatness, Hus AMA class A applies according to the current edition.

When laying on concrete, a maximum RH of 85% applies, measured according to the industry standard.

Remember to remove dust, loose dirt, stains from paint, oil and the like to avoid poor adhesion.

If there is underfloor heating, the subfloor must be flat and stable. Tiles may be exposed to a maximum of 27°C.

Smooth out any unevenness with putty or smoothing compound of suitable strength for the activities in the premises.

The subfloor must be level and absorbent/floating putty.

Mounting

The glue must be suitable for PVC-free luxury tile and suitable in relation to the conditions and area of use for the premises.

Follow the glue manufacturer's instructions regarding glue quantity, glue spreader and installation time.

Ensure over wetting of adhesive to the back of the plate.

Do not glue a larger surface than you have time to lay the tiles in the appropriate time.

Immediately after installation, the tiles must be rolled with a floor roller of at least 45 kg. Roll the floor in both directions.

The newly laid floor must be covered if further construction activities are to be carried out. Use diffusion-open cover material in accordance with Hus AMA and GBR's technical advice.

Do not tape directly to the tiles.

Guarantee

Validity

Idé Flooring Sverige AB provides a 10-year guarantee on the wear layer of the slab. The warranty period is calculated from the invoice date.

The warranty does not apply if:

- Floors with visible cosmetic defects or damage have been installed.
- The floor is not installed by an authorized professional.
- Installation instructions not followed.
- Cleaning instructions not followed.
- The floor is or has been exposed to solar heat more than 35 degrees.
- The subfloor does not hold Class A ± 2 mm on 2 meters or ± 0.25 mm on 25 cm.
- The floor has been exposed to scratch damage, paint spills, abnormally heavy loads, mechanical damage, hydraulic pressure (such as lifts, trucks, etc.).
- The floor has not been laid on a hard, even, smooth, non-yielding or incorrect surface.
- The floor is laid on concrete with RH above 85%.
- Floor protection under office chairs with wheels that have not been used.
- Furniture feet have not been used under chair legs.
- Underfloor heating exceeds 27 degrees.